


Remote Controller



Diagnostic Use of Controller

- To Display Maintenance Codes: Press the 'On/Off' button once to turn the controller off. Press and hold the 'On/Off' button followed by the thermostat button to cycle through the maintenance codes.
- To Display Water Flow through the water heater: Press the thermostat button and hold for 2 seconds and then press the 'On/Off' button while continuing to hold the thermostat button.
- To Display Outlet Water Temperature: Press the thermostat button and hold for 2 seconds and then press the 'On/Off' button while continuing to hold the thermostat button.

To Change the Temperature Display from °F to °C (or °C to °F)

- Press the 'On/Off' button once to turn the controller unit off. With the controller off press and hold the 'On/Off' button until the display changes to °C (°F), approximately 5 seconds.

To Turn Off the Sound (Mute)

- To turn the sound off (mute) press and hold both the and thermostat buttons until an audible "beep" is heard, approximately 5 seconds.

Gas Pressure Setting

NOTE: For additional installation and commissioning information refer to Operation / Installation Manual



THIS APPLIANCE MUST BE INSTALLED, SERVICED AND REMOVED BY AN AUTHORISED PERSON DURING PRESSURE TESTING OF THE CONSUMER PIPING ENSURE GAS COCK SITUATED BEFORE UNIT IS SHUT-OFF. FAILURE TO DO SO MAY RESULT IN SERIOUS DAMAGE TO THE APPLIANCE AND POSSIBLE INJURY.


APPLIANCE OPERATING PRESSURES

Table 1

Water Inlet Min.	Gas Inlet Min./Max.		Forced Low		Forced High	
	NAT.G	LPG	NAT.G	LPG	NAT.G	LPG
505	150 PSI 5'W.C. /10.5'W.C.	8'W.C. /13.5'W.C.	0.52'W.C.	0.92'W.C.	3.3'W.C.	5.0'W.C.
305						

COMMISSIONING

With all gas appliances in operation at maximum gas rate, the flowing inlet pressure at the incoming test point on the Water Heater should read 5'W.C. - 10.5'W.C. on Natural Gas and 8'W.C. - 13.5'W.C. on Propane Gas. If the pressure is lower, the gas supply is inadequate and the appliance unit will not operate to specification. Check gas meter, regulator and pipework for correct operation/sizing and rectify as required.



Troubleshooting

IMPORTANT SAFETY NOTES:

There are a number of (live) tests that are required when fault finding this product. Extreme care should be used at all times to avoid contact with energized components inside the water heater. Only trained and qualified service agencies should attempt to repair this product. Remember, before checking for resistance readings, you should disconnect the power source to the unit and isolate the item to be checked from the circuit (unplug it).

(SV1, SV2, SV3 and POV) Gas valve and Modulating solenoids: (Set meter above 2K)

Wire color	Voltage	Resistance	Connector #	Pin #'s
(Main) Pink - Black	11 - 13 VDC	36.8 - 44.8 ohms	H5	6 - 7
(SV1) Black - Yellow	11 - 13 VDC	36.8 - 44.8 ohms	H6	5 - 6
(SV2) Black - Blue	11 - 13 VDC	36.8 - 44.8 ohms	H7	4 - 6
(SV3) Black - Brown	11 - 13 VDC	36.8 - 44.8 ohms	H8	3 - 6
(POV) Pink - Pink	2 - 15 VDC	67 - 81 ohms	H3	9 - 10

(M) Water Flow Control Device Servo or Geared Motor:

Red - Blue	11 - 13 VDC	22 - 28 ohms	F7	9 - 10
Grey - Brown	4 - 6 VDC	N/A	F7	5 - 7
Grey - Yellow	N/A	N/A	F7	5 - 8

NOTE: The grey wire listed above turns to black at B connector on the PCB, the orange wires turn to red.

(QS) Water Flow Sensor:

Black - Red	11 - 13 VDC	5.5 - 6.2 K ohms	F2	1 - 3
Yellow - Black	4 - 7 VDC	1 - 1.4 Mega ohms	F2	2 - 3

By-pass Flow Control (By-pass servo model ONLY):

Brown - White	2 - 6 VDC	15 - 35 ohms	G1	1 - 5
Orange - White	N/A	N/A	G1	2 - 5
Yellow - White	(Unit in operating mode)	G1	3 - 5	
Red-White - Ground		G1	4 - 5	

(IG) Ignition System:

Grey - Grey	90 - 110 VAC	N/A	C1	1 - 2
-------------	--------------	-----	----	-------

(FM) Combustion Fan Motor:

Red - Black	6 - 45 VDC	N/A	E1	1 - 2
White - Black	5 - 10 VDC	9.2 - 9.4 K ohms	E1	2 - 4
Yellow - Black	11 - 13 VDC	3.5 - 3.9 K ohms	E1	3 - 4

Set your meter to the hertz scale. Reading across the white and black wires at terminals 2 and 3 you should read between 60 and 420 hertz.


Thermal Fuse / Overheat Switch:

Red - Red	11 - 13 VDC	Below 1 ohms	F6	F6 - H12
-----------	-------------	--------------	----	----------

Dip Switches Settings

Adjust switches 2 and 3 in the bank of 8 depending on your altitude according to the table below.

The original PC boards on the water heaters do not have the bank of 6 dip switches. Only spare PC boards have this bank.




DO NOT adjust the other dip switches unless specifically instructed to do so. Incorrect Dip Switch Settings can cause the water heater to operate in an unsafe condition and may damage the water heater and void the warranty.

SW No.	NOTES								
	2	High Altitude	Off	Level 0 (0-2000ft)	Off	Level 1 (2001-5200ft (610-1585m))	On	Level 2 (5201-7800ft (1585-2377m))	On


Error Codes

- | | |
|--|---|
| 02 No burner operation during freeze protection mode | 16 Over Temperature Warning |
| • Service Call | • Check for restrictions in air flow around unit and vent terminal. |
| 03 Power interruption during Bath fill (Water will not flow when power returns) | • Check for low water flow in a circulating system causing short cycling. |
| • Turn off all hot water taps. Press ON/OFF twice. | • Check for foreign materials in combustion chamber and/or exhaust piping. |
| 10 Air Supply or Exhaust Blockage | • Check for clogged heat exchanger. |
| • Ensure approved venting materials are being used. | • Check for damage. |
| • Check that nothing is blocking the flue inlet or exhaust. | • Measure resistance of sensor. |
| • Check all vent components for proper connections. | • Clean sensor of scale build up. |
| • Ensure vent length is within limits. | • Replace sensor. |
| • Ensure condensation collar was installed correctly. | |
| • Verify dip switches are set properly. | |
| • Check fan for blockage. | |
| 11 No Ignition | 32 Outgoing Water Temperature Sensor Fault |
| • Check that the gas is turned on at the water heater, gas meter, or cylinder. | • Check sensor wiring for damage. |
| • Ensure gas type and pressure is correct. | • Measure resistance of sensor. |
| • Ensure gas line, meter, and/or regulator is sized properly. | • Clean sensor of scale build up. |
| • Bleed all air from gas lines. | • Replace sensor. |
| • Verify dip switches are set properly. | |
| • Ensure appliance is properly grounded. | |
| • Disconnect EZConnect or MSA controls to isolate the problem. | |
| • Ensure igniter is operational. | |
| • Check igniter wiring harness for damage. | |
| • Check gas solenoid valves for open or short circuits. | |
| • Remove burner cover and ensure all burners are properly seated. | |
| • Remove burner plate and inspect burner surface for condensation or debris. | |
| 12 Flame Failure | 33 Heat Exchanger Outgoing Temperature Sensor Fault |
| • Check that the gas is turned on at the water heater and gas meter. Check for obstructions in the flue outlet. | • Check sensor wiring for damage. |
| • Ensure gas line, meter, and/or regulator is sized properly. | • Measure resistance of sensor. |
| • Ensure gas type and pressure is correct. | • Clean sensor of scale build up. |
| • Bleed all air from gas lines. | • Replace sensor. |
| • Ensure proper venting material was installed. | |
| • Ensure condensation collar was installed properly. | |
| • Ensure vent length is within limits. | |
| • Verify dip switches are set properly. | |
| • Ensure appliance is properly grounded. | |
| • Disconnect keypad. | |
| • Check power supply for loose connections. | |
| • Check power supply for proper voltage and voltage drops. | |
| • Ensure flame rod wire is connected. | |
| • Check flame rod for carbon build-up. | |
| • Disconnect and re-connect all wiring harnesses on unit and PC board. | |
| • Check all components for electrical short. | |
| • Check gas solenoid valves for open or short circuits. | |
| • Remove burner plate and inspect burner surface for condensation or debris. | |
| 14 Thermal Fuse | 52 Modulating Solenoid Valve Signal Abnormal |
| • Check gas type of unit and ensure it matches gas type being used. | • Check modulating gas solenoid valve wiring harness for loose or damage terminals. |
| • Check for restrictions in air flow around unit and vent terminal. | • Measure resistance of valve coil. |
| • Check for low water flow in a circulating system causing short cycling. | |
| • Ensure dip switches are set to the proper position. | |
| • Check for foreign materials in combustion chamber and/or exhaust piping. | |
| • Check heat exchanger for cracks and/or separations. | |
| • Check heat exchanger surface for hot spots which indicate blockage due to scale build up. Refer to instructions in manual for flushing heat exchanger. | |
| • Measure resistance of safety circuit. | |
| • Ensure high fire and low fire manifold pressure is correct. | |
| • Check for improper conversion of product. | |
| LC Scale Build-up in Heat Exchanger (when checking maintenance code history "00" is substituted for "LC") | |
| • Flush heat exchanger. Refer to instructions in manual. | |
| • Replace heat exchanger. | |
| No Code (Nothing happens when water flow is activated.) | |
| • Clean inlet water supply filter. | |
| • On new installations ensure hot and cold water lines are not reversed. | |
| • Check for bleed over. Isolate unit from building by turning off hot water line to building. Isolate the circulating system if present. Open your pressure relief valve; if unit fires, there is bleed over in your plumbing. | |
| • Ensure you have at least the minimum flow rate required to fire unit. | |
| • Ensure turbine spins freely. | |
| • Measure the resistance of the water flow control sensor. | |
| • Remote control does not light up but you have 12 VDC at the terminals for controls. | |


Wiring Diagram




EXPLODED VIEW - CABINET




EXPLODED VIEW - INTERNALS



EXPLODED VIEW - INTERNALS



EXPLODED VIEW - ELECTRICAL



PARTS LIST

Number	Description	Parts Number	Quantity	Number	Description	Parts Number	Quantity	Number	Description	Parts Number	Quantity
		505	305			505	305			505	305
001	Main Body (FFU)	701022-004	1	140	Air Inlet Box Frame	701022-056	1	713	Anti Frost Heater (120V)	701022-098	1
002	Wall Mounting Bracket (FFU)	701022-006	1	141	Joint Exhaust Tube Frame Supporter	701022-057	2	715	Valve Heater (120V) Assembly	701022-100	1
003	Rubber Bushing	701022-008	1	142	Air Inlet Box Cover	701022-058	1	716	Antifrost Heater Clip B	701022-102	2
004	Connection Reinforcement Panel	701022-009	1	143	Heat Exchanger Assembly	701022-059	1	717	Antifrost Heater Clip A	701022-103	1
005	Heat Protection Plate	701022-010	1	144	Flue Connection Assembly	701022-060	-	718	Antifrost Heater Clip C	701022-105	1
006	Front Panel	701022-011	1	145	O-ring	701022-064	1	719	Inlet Air Thermistor	701022-106	1
008	Front Panel Packing Side	701022-014	2	146	O-ring	701022-065	1	720	Power Cord	701022-107	1
009	Remote Controller Ass'y	701022-015	1	147	Pipe Seal	701022-066	1	721	Fuse Harness (FF)	701022-108	1
010	Remote Controller Bracket	701022-016	1	148	Cap	701022-067	1	722	Power Harness	701022-110	1
011	Screw Cover	701022-017	2	400	Water Inlet (3/4" NPT)	701022-069	1	723	Solenoid Valve Harness	701022-111	1
012	Screw Cover Lid	701022-018	4	401	Water Flow Servo & Sensor Assembly	701022-071	1	724	Sensor Harness	701022-112	-
014	Rubber Bushing	701022-020	1	402	Rectifier	701022-073	1	725	Thermal Fuse Harness Assy	701022-116	1
016	Packing	701022-023	1	403	By-pass Servo Assembly	701022-074	1	726	Ignitor Harness	701022-117	1
017	Screw Cover Assy	701022-024	2	404	Stop Bracket	701022-075	2	727	Flow Sensor	701022-118	1
100	Gas Control Assembly	701022-025	1	405	Stop Bracket	701022-076	-	729	Remote Controller Harness	701022-119	1
101	Test Port Set Screw	701022-026	2	406	Plug Band	701022-077	1	730	Thermistor	701022-120	1
102	Gas Connection (3/4" NPT)	701022-027	1	407	Hot Water Outlet (3/4" NPT)	701022-078	1	800	Screw	701022-121	8
103	Burner Unit Assy (LPG)	701022-028	1	408	Stop Bracket	701022-079	1	801	Screw	701022-122	4
103A	Burner Unit Assy (NG)	701022-029	1	409	Plug Band (small)	701022-080	1	802	Resin Washer	701022-123	4
103A	24 Damper (NG)	701022-030	1	410	Drain Valve	701022-081	1	803	O-ring	701022-124	3
110	Manifold Assembly (LPG)	701022-031	1	411	Water Filter Assy	701022-082	1	804	Thermistor Stop Screw	701022-125	1
110	Manifold Assembly (FF-NG)	701022-032	1	412	Cover	701022-083	1	805	Screw	701022-126	3
113	Pressure Point Sealing Screw	701022-034	1	700	PCB	701022-084	1	810	O-ring	701022-130	2
114	Combustion Chamber Sightglass Plate	701022-035	1	701	PCB cover - side	701022-088	1	810	O-ring	701022-131	1
116	Electrode	701022-036	1	702	PCB cover - front	701022-090	1	812	O-ring	701022-132	1
117	Flame Rod	701022-037	1	703	Surge Protector	701022-091	1	813	O-ring	701022-133	2
118	Electrode Packing	701022-038	1	706	Surge Protector with terminal (optional)	701022-097	1	814	O-ring	701022-134	2
119	Electrode Holder	701022-039	1	707	PCB	701022-098	1	815	O-ring	701022-135	2
119A	Sparkler Bracket	701022-040	1	708	High Tension Cord	701022-099	1	816	O-ring	701022-136	1
121	Tube Joint	701022-041	1	709	Electrode Sleeve	701022-099	1	817	O-ring	701022-137	1
122	Vent Tube	701022-042	1	710	Thermistor - Heat Exchanger	701022-099	1	818	Packing	701022-138	2
125	Fan Assembly	701022-043	1	711	Thermistor Clip Large	701022-099	1	819	Screw	701022-139	2
131	Rubber Boot Bracket Right	701022-046	1	712	Temperature Fuse Clip	701022-099	1	820	Screw	701022-140	4
132	Combustion Chamber Fan Bracket	701022-047	1	713	Frost Sensing Switch	701022-099	5	821	Screw	701022-141	2
135	Air Inlet Box All Assembly	701022-048	1	714		701022-099	5	822	Screw	701022-142	3
136	Rubber Boot Bracket Left	701022-050	1	715		701022-099	5	888	Manual	701022-143	1
137	Rubber Boot	701022-051	1	716		701022-099	5	889	Tech Sheet	701022-145	1
138	Rubber Boot Clamping Ring	701022-053	1	717		701022-099	5				
139	Air Inlet Duct	701022-055	1	718		701022-099	5				